# AIR DIFFUSION AGENCIES PTY LTD ABN 008 267 221

## **CHIMNEY KIT INSTALLATION GUIDE**

#### **CONTENTS**

- 4 x Stainless Steel Flue 900mm long
- 1 x Stainless Steel Flue 450mm
- 1 x Galvanised Chimney Plate
- 1 x Spun Cowl
- 1 x Installation Guide

#### **INSTRUCTIONS**

- 1. Locate the Heater in accordance with the Australian Standards AS2918:2018 and as per <u>manufacturer</u> recommendations.
- Join lengths of Stainless Steel Flue together, crimped end must always face down. Pass the flue Pipe up or down Chimney, whichever is easier, Crimped end first. You may find it easier to join lengths of Flue together first.
- 3. Fit Chimney Plate to the top of Chimney. Cement over the base plate. Angle the cement to allow water runoff.
- 4. The top length of Flue should finish to ensure that it fits onto the cowl stem by 25mm. Active Flue will require cutting for this to happen.
- 5. Cut 4 x 25mm tags in the Chimney Plate to allow the Flue System to Ventilate.
- 6. Fit Cowl over the Flue and Chimney Plate and secure tags.

### **WARNINGS**

- Please note that this Installation Guide may not apply in all situations. Some houses have higher roofs, therefore extra Flue may be required.
- Before commencing installation, it is recommended that you check with your local council regarding any
  regulations, which may apply to the installation of this type. If the installation does not comply with
  Australian Standard AS2918:2018, it would not comply with Australian Building Code.
- It is recommended that a professional Chimney Sweeper checks your Flue regularly for Soot build up and also to conduct general maintenance.
- When lighting your first fire, test the system with a few sheets rolled up newspaper to make sure the Flue is clear and to cure all painted surfaces. Continue with a small fire until this has been achieved.

IT IS STRONGLY RECOMMENDED THAT INSTALLATIONS ONLY BE CONDUCTED BY A QUALIFIED WOOD HEATING INSTALLER.